



WHAT YOU NEED TO KNOW:

2020-2014 GM 1500 TRUCK & SUV BALL JOINT IDENTIFICATION

SUPREME

Beginning MY2014, GM introduced multiple front upper and lower control arm types for 1500 Trucks and certain SUVs. These varying control arm types are distinguished by their material composition and ball joint taper.

For a frustration-free repair, follow the guide below when ordering Supreme replacement front upper and lower ball joints.

FRONT UPPER CONTROL ARMS		
IF ORIGINALLY EQUIPPED WITH:		SUPREME
 <p>Model Year: 2016-2007 Control Arm Construction: Cast Iron</p>		 <p>CMK80669 – Front Left Upper CMK80670 – Front Right Upper</p>
 <p>Model Year: 2016-2014 Control Arm Construction: Aluminum</p>		 <p>CMS501234 – Front Left Upper CMS501233 – Front Right Upper</p>
 <p>Model Year: 2018-2016.5 Control Arm Construction: Stamped Steel</p>		 <p>MS50575 – Front Upper</p>
FRONT LOWER CONTROL ARMS		
IF ORIGINALLY EQUIPPED WITH:		SUPREME
 <p>Model Year: 2016-2007 Control Arm Construction: Cast Iron</p>		 <p>MK6541 – Front Lower</p>
 <p>Model Year: 2014-2007 Control Arm Construction: Aluminum</p>		 <p>MK500007 – Front Lower</p>
 <p>Model Year: 2019-2015 Control Arm Construction: Aluminum</p>		 <p>MS50532 – Front Lower</p>
 <p>Model Year: 2020-2016 Control Arm Construction: Stamped Steel</p>		 <p>MS50580 – Front Lower</p>