WHAT YOU NEED TO KNOW:
2020-2014 GM 1500 TRUCK & SUV BALL JOINT IDENTIFICATION

SUPREME

Beginning MY2014, GM introduced multiple front upper and lower control arm types for 1500 Trucks and certain SUVs. These varying control arm types are distinguished by their material composition and ball joint taper.

For a frustration-free repair, follow the guide below when ordering Supreme replacement front upper and lower ball joints.

FRONT UPPER CONTROL ARMS

IF ORIGINALLY EQUIPPED WITH:		SUPREME
 **Model Year: 2016-2007** Control Arm Construction: **Cast Iron**	**REPLACE WITH**	**CMK80669** – Front Left Upper **CMK80670** – Front Right Upper 
 **Model Year: 2016-2014** Control Arm Construction: **Aluminum**	**REPLACE WITH**	**CMS501234** – Front Left Upper **CMS501233** – Front Right Upper 
 **Model Year: 2018-2016.5** Control Arm Construction: **Stamped Steel**	**USE WITH**	**MS50575** – Front Upper 

FRONT LOWER CONTROL ARMS

IF ORIGINALLY EQUIPPED WITH:		SUPREME
 **Model Year: 2016-2007** Control Arm Construction: **Cast Iron**	**USE WITH**	**MK6541** – Front Lower 
 **Model Year: 2014-2007** Control Arm Construction: **Aluminum**	**USE WITH**	**MK500007** – Front Lower 
 **Model Year: 2019-2015** Control Arm Construction: **Aluminum**	**USE WITH**	**MS50532** – Front Lower 
 **Model Year: 2020-2016** Control Arm Construction: **Stamped Steel**	**USE WITH**	**MS50580** – Front Lower 

Mevotech LP. | ©2026 No reproduction in whole or in part without prior written approval.

SUPREME