MEVOTECH INSIDER
Service Tips and Best Practices

Correct Installation Orientation: 2021-1999 GM 2500-3500-4500 Van Front Upper Ball Joint

Brand	Supreme	Product	Ball Joint	Date	March 2023
Part Number(s)	MK6694				


To ensure proper part performance, the below noted ball joint must be pressed-in using the correct orientation when mating to the front upper control arm.

Part Number:
MK6694

For a successful repair outcome, adhere to the following:

- Before installation of ball joint, ensure all mating surfaces are clear of rust, debris and burrs. Inspect control arm mounting flange for cracks, deformation and or an out of round condition. Do not reuse control arm body if these are found. **See Figure 1.**

Figure 1.



- Verify press-in diameters and stud tolerances, including on steering knuckle side. Replace all damaged or out-of-specification mating components.
- When pressing-in ball joint, ensure pressure is applied to the mounting flange and not the ball joint back plate. Contact with the back plate during install may lead to damage and or impaired performance of the ball joint.
- Locate drilled index mark on ball joint flange. **See Figure 2.**
- Before press-in, it is recommended to create an alignment mark on both control arm and ball joint housing using a suitable implement, such as a grease pencil. This will assist in attaining correct orientation during press-in.

WE SUPPORT ASE CERTIFICATION

DISCLAIMER: The information in this communication is intended for use only by skilled technicians who have the proper tools, equipment and training to correctly and safely maintain vehicles. Refer to original manufacturers service manual for proper torque specifications and removal/installation procedures. All content in the publication is provided as-is and without warranty. All care has been taken to ensure the accuracy of the information presented. The publisher assumes no responsibility or liability for any loss or damage, direct, indirect or consequential, arising from the use of the information contained herein.

Correct Installation Orientation: 2021-1999 GM 2500-3500-4500 Van Front Upper Ball Joint



Figure 2. Drilled index mark on ball joint flange (callout box)

- During press-in, index mark must be oriented so that it is perpendicular to the wheel (facing outboard). For an illustration of correct installation orientation, **see Figure 3.**




Figure 3. Correct ball joint installation orientation when mated to front upper control arm. Note drilled index mark position (highlighted orange box)

Always ensure to refer to the factory service manual for correct diagnostic procedures, component removal and installation methods and fastening torque values and procedures where applicable. Only use a calibrated torque wrench for final fastening.

WE SUPPORT
ASE CERTIFICATION

DISCLAIMER: The information in this communication is intended for use only by skilled technicians who have the proper tools, equipment and training to correctly and safely maintain vehicles. Refer to original manufacturers service manual for proper torque specifications and removal/installation procedures. All content in the publication is provided as-is and without warranty. All care has been taken to ensure the accuracy of the information presented. The publisher assumes no responsibility or liability for any loss or damage, direct, indirect or consequential, arising from the use of the information contained herein.